

Air Spring

S/N	PICTURE	FAT NO.	OEM NO.	MODEL
 MERCEDES BENZ				
1		FAT-AS-211	2113200925	Mercedes E-Class W211 S211 4matic Rear Left/Right
2		FAT-AS-211L	2113200725 2113201525	E-Class W211 S211 W207 2002- 2009 CLS-Class W219 Rear Left
3		FAT-AS-211R	2113200825 2113201625	E-Class W211 S211 W207 2002- 2009 CLS-Class W219 Rear Right
4		FAT-AS-019	2213201738 2213201838	Mercedes W221 S-Class 2WD/4matic 2007-2012 Front Left/Right
5		FAT-AS-020	2213205513 2213205613	Mercedes S-Class W221 S350 S500 2WD/4matic CL-Class W216 2007-2012 Rear Left/Right
6		FAT-AS-166L	1663201313 1663206713 1663206913	Mercedes GL-Class,ML-ClassBenz W166 2011- Front Left
7		FAT-AS-166R	1663201313 1663206713 1663206913	Mercedes GL-Class,ML-ClassBenz W166 2011- Front Right
8		FAT-AS-008	2513200325 2513200425 2513200025	Mercedes-Benz R-Class W251/R350 R500 2006-2010 Rear Left/Right
9		FAT-AS-004	2513203013 2513203113 2513205613 2513205713	Mercedes-Benz R-Class W251/R350 2006-2010Front

10		FAT-AS-007	1643201025 1643200925	Mercedes-Benz X164 GL- Class/W164 GL-ClassGL350 GL450 Rear Left/Right
11		FAT-AS-003	1643206013 1643206113 1643204313	Mercedes-Benz W164 ML GL Front Left/Right
12		FAT-AS-009	1643200625 1643200925 1643200225	Mercedes-Benz W164/ ML350 ML500
13		FAT-AS-017	2203202438 2203205113	W220 S-Class 1999-2006 Front Left/Right
14		FAT-AS-018	2203205013	W220 S-Class 1999-2006 Rear Left/Right
15		FAT-AS-021	2123200325 2123203725 2123202125	Mercedes-Benz W212 Rear Left
16		FAT-AS-022	2123200625 2123203825 2123202025	Mercedes-Benz W212 Rear Right
17		FAT-AS-023	6383280501 6383280601 6383280701	Mercedes V-Class/Vito W638 1996-2003 Rear Left/Right
18		FAT-AS-024	6393280101 6393280201 6393280301	Mercedes V-Class/Vito W639 2003- Rear Left/Right
 Audi				
19		FAT-AS-001	4Z7616051D 4Z7616051B	Audi A6 (4B,C5) Allroad 2000-2006 Front Left/Right

20		FAT-AS-002R	4Z7616051 4Z7616051A	Audi A6 (4B,C5) Allroad 2000-2006 Rear Left
21		FAT-AS-002L	4Z7616052 4Z7616052A	Audi A6 C5 Allroad 2000-2006 Rear Right
22		FAT-AS-015	4F0616001 4F0616001J	Audi A6 (C6,4F) Allroad 07-10 A6(4F,C6,S6,A6L,Avant) 04-11 Rear Left/Right
23		FAT-AS-A8	4E0616039AB 4E0616039T 4E0616039AF	Audi A8 (D3,4E) 2002-2011 Front Left & Right
24		FAT-AS-239	L 4E0 616 001E(XB) R 4E0 616 002E(XB)	Audi A8 (D3,4E) 2002-2011 rear Left & Right
25		FAT-AS-025	7L6-616-403B 7L5616403B 7L5616403E	Audi Q7,VW Touarge,Cayenne 2004-2010 Front Left
26		FAT-AS-026	7L6-616-404B 7L6616404B 7L6616404E	Audi Q7,VW Touarge,Cayenne 2004-2010 Front Right
27		FAT-AS-027	7L6616503B 7L6616503A 7L5616503F	Audi Q7,VW Touarge,Cayenne 2004-2010 Rear
28		FAT-AS-39K	7P6616039K 7P6616039N 7P6616039M	Audi Q7 VW Touareg Porsche Cayenne New model 2011-2016 front left
29		FAT-AS-40K	7P6616040K 7P6616040N 7P6616040M	Audi Q7 VW Porsche New model 2011-2016 front right

30		FAT-AS-503	7P6616503G 7P6616503H 7P6616503J	Audi Q7 VW Touareg Porsche Cayenne New model Rear Left
31		FAT-AS-504	7P6616504G 7P6616504H 7P6616504J	Audi Q7 VW Touareg Porsche Cayenne New model Rear right
32		FAT-AS-67001L	4G0616001K	Audi A6 4G C7 Allroad Avant 2011 Rear left
33		FAT-AS-67001R	4G0616002K	AUDI A6 4G C7 2011 Rear right
 BMW				
34		FAT-AS-X5L	37116757501 37116761443	BMW X5 E53 1999-2006 Front Left
35		FAT-AS-X5R	37116757502 37116761444	BMW X5 E53 1999-2006 Front Right
36		FAT-AS-010	37126750355 37121095579	BMW X5/E53 2000-2006 Rear Left
37		FAT-AS-011	37126750356 37121095580	BMW X5/E53 2000-2006 Rear Right
38		FAT-AS-012	37121094613 37121095081 A7058P01	BMW Series E39 Touring 1995-2003 Rear Left
39		FAT-AS-013	37121094614 37121095082	BMW Series E39 Touring 1995-2003Rear Right

40		FAT-AS-005	37106781827 37106781828 37106781843	BMW 5er GT (F07) 2009 5er (F11 Touring) 2010 Rear Left/Right
41		FAT-AS-006	37126790078 37126790079 37126790080	BMW X5 (E70, M) 2007, X6 (E71, E72, M) 2008 Rear Left/Right
42		FAT-AS-115	37126795013 37126795014	BMW X5 F15 BMW X6 F16 2013-2016 Rear
43		FAT-AS-014	37126765602 37126765603	BMW E61 2002-2010 Rear Left/Right
44		FAT-AS-811	37126858811 37106791675 37126794139	BMW 7er (F01/F02/F04) 2007 rear left
45		FAT-AS-812	37126858812 37106791676 37126794140	BMW 7er (F01/F02/F04) 2007 rear right
 Land Rover				
46		FAT-LD-322L	RNB000750G	Range Rover L322 2002-2009 Front Left
47		FAT-LD-322R	RNB000740G	Range Rover L322 2002-2009 Front Right
48		FAT-AS-016	RKB500082 RKB000150 RKB000151	Range Rover 2 2003-2009 (L322) Rear Left/Right
49		FAT-AS-580G	RN501580G	Discovery 3 2004-

50		FAT-AS-090	RTD501090 LR016402 LR016404 RPD000305	Discovery 3 2004-2009 Discovery 4 2009-2013 Rear Left/Right with dust boot Land Rover Discovery Range Rover Sport Rear
51		FAT-LD-003	RKB101200	Land Rover Discovery 2 1998-2004 Contitech SK 112-24 Rear Left/Right
52		FAT-LD-250	RNB501580 RNB501250 RNB501620	Discovery 3 05-09 Discovery 4 10-13, Range Rover Sport 05-13 front left/right
53		FAT-LD-411	LR016411 RKB500250	Discovery 3 05-09 Discovery 4 10-13, Range Rover Sport 06-12 front left/right with out dust boot
54		FAT-AS-550	REB000550 REB101740 REB101740E	Range Rover 2 1994-2002 (P38) Front
55		FAT-AS-460	RKB101460 RKB101460E	Range Rover 2 1994-2002 (P38) Rear
56		FAT-AS-5580	LR034262, LR052171,DPLA-5580-AD, DPLA5580AD. CPLA-5580-AB	Range Rover Full Size L405 2013-2015 REAR AIR SPRING
 Porsche				
57		FAT-PRO-991L	97034305108 97034305109 97034305110 97034305111 97034305112 97034305114	Porsche Panamera Front Left
58		FAT-PRO-991R	97034305208 97034305209 97034305210 97034305211 97034305212 97034305214	Porsche Panamera Front Right
59		FAT-AS-040	95535840410 P95535840410 95535840431 P95535840431 A95535840400 95535840421	Porsche Cayenne I 2002-2007 Porsche Cayenne I (Facelift) 2007-2010 Front Right with mounting and valve

60		FAT-AS-039	95535840320 95535840321 95535840330 95535840331	Porsche Cayenne I 2002-2007 Porsche Cayenne I (Facelift) 2007-2010 Front Left with mounting and valve
61		FAT-AS-3312	97033153312	Porsche 970 Panamera 4S, Turbo Air spring
 VW				
62		FAT-PA-001	3D0616039 3W0616039 3W5616039 3W7616039 3W8616039 3W0616040	Bentley Continental and VW Phaeton Front Left/Right
63		FAT-BLY-002	L 3W0 616 039T(XB) R 3W0 616 040T(XB)	Bentley Continental rear air bag
64		FAT-PA-002	7L6 616 503B	Volkswagen Audi Q7 Cayenne rear repair kit
 Lincoln / Ford 				
65		FAT-LIN-7039	61F-15 7L1Z5A891B 8L1Z5A891B 7L1Z5A891A	Lincoln Navigator 2007 Rear
66		FAT-FORD-7000	3U2Z5580BA 3U2Z5580PA	Ford Crown Victoria 1992-2011(4.6L V8) Rear Lincoln Town Car 1990-1997(5.0 4.6 V8) Rear
67		FAT-FORD-7001	3U2Z5580KA 1L1Z5319AA 1L1Z5319BA 6L1Z5319AA	Ford Expedition (2 W) 97-02 Rear Left/Right Lincoln Navigator (2 W) 98-02 Rear Left/Right
68		FAT-FORD-7002	1L1Z5319BA 6L1Z5319AA 3U2Z5580LA 1L1Z5319AA	Ford Expedition (4W) 1997-2002 Rear Left/Right
69		FAT-FORD-2051	6L1Z3C199AA 4L1Z3C199AA 2L1Z3C199AA	Ford Expedition / Lincoln Navigator 2003-2006 (All Models) Front Left/Right

70		FAT-FORD-7051	4L1Z5A891AA 6L1Z5A891AA 2L1Z5A965AA	Ford Expedition / Lincoln Navigator 2003-2006 (All Models) Rear Left/Right
71		FAT-LIN-705R	3U2Z5580MA 3U2Z5580HA	Lincoln Continental 1995-2002 (4.6 Liter V8) Rear Right
72		FAT-LIN-705L	3U2Z5580NA 3U2Z5580JA	Lincoln Continental 1995-2002 (4.6 Liter V8) Rear Left
73		FAT-LIN-703R	3U2Z5310CA 3U2Z5310DA	Lincoln Continental 1995-1996 (4.6 Liter V8) Front Right
74		FAT-LIN-703L	3U2Z5310CA 3U2Z5310DA	Lincoln Continental 1995-1996 (4.6 Liter V8) Front Left
75		FAT-LIN-7006	F1LY5310B F1LY5310A	Lincoln Continental 1984-1987 (5.0 Liter V8) 84-87 5.0L V8 Front Left/Right Mark VII (7) 1984-1992 (5.0 Liter V8) Front Left/Right

 Toyota

76		FAT-TO-001L	48080-35011	Toyota Land Cruiser Prado 120 2002-2009, 4Runner Lexus GX470 2003-2009 Rear Left
77		FAT-TO-001R	48090-35011 48080-35012	Toyota Land Cruiser Prado 120 2002-2009, 4Runner Lexus GX470 2003-2009 Rear Right
78		FAT-TO-002L	48090-60010	Toyota Land Cruiser prado Rear Left
79		FAT-TO-002R	48080-60010	Toyota Land Cruiser prado Rear Right

 Jeep

80		FAT-JP-001	68029912AE 68029911AB 68029912AC 68029912AD	Jeep Grand Cherokee WK2 2011-2013 Rear Left/Right
 Hummer/Chevrolet				
81		FAT-HM-001	GM-15938306 15938306	Hummer H2 2003-2009 Chevrolet Trailblazer 2002-2009 Rear
HY				
82		FAT-HY-001	55350-3M501	Hyundai Equus Centennial 2009- 2013 Air Suspension REAR left pneumatic
83		FAT-HY-002	55350-3M502	Hyundai Equus Centennial 2009- 2013 Air Suspension REAR Right pneumatic
Others				
84		FAT-SAAB-001	25815604 15125532 15276029	2002-2009 Buick Rainier 2002-2009 Saab 9-7x 2002-2009 Oldsmobile Bravada 2002-2009 Lsuzu Ascender 2002-2009 Chevrolet Trailblazer 2002-2009 GMC Envoy
85		FAT-CIT-001	5102GN 5102 GN 5102R8 5102 R8 F307512401 9676670180b_00	Citroen Picasso C4 rear
86		FAT-VO-622	20462600 21165207 8074629	Volvo air spring
87		FAT-GMC-5604	25815604 15125532 5276029 25878674	Air Springs for GMC Chevy Buick Isuzu Olds Saab