

FAT Air suspension the best quality for all !!!

GUANG ZHOU FAT CHASSIS TECHNOLOGY CO.,LIMITED

S/N	PICTURE	FAT NO.	OEM NO.	MODEL
 Rolls-Royce				
1		FAT-RR-001	37106796508	RollsRoyce Phantom2003-2016FrontOEMREBUILD-Suspension-Air-Spring-Bag-Strut
2		FAT-RR-003	37106785171	Rolls-Royce Phantom 2003-2016 Rear Left REBUILD Suspension Air Spring Bag Strut
3		FAT-RR-002	37106785172 37126761014	Rolls-Royce Phantom 2003-2016 Rear Right REBUILD Suspension Air Spring Bag Strut
4		FAT-RR-551	37106862551	Rolls-Royce Ghost '10-'14 Front Left OEM REBUILD Suspension Air Spring Bag Strut
5		FAT-RR-552	37106862552	Rolls-Royce Ghost '10-'14 Front RIGHT OEM REBUILD Suspension Air Spring Bag Strut
 MERCEDES BENZ				
ABC Shock				
6		FAT-MB-005	220 320 1538 220 320 8113 220 320 0138	W220 (03-06) with ABC S55 AMG S65 AMG front left
7		FAT-MB-006	220 320 1638 220 320 8213 220 320 0238	W220 (03-06) with ABC S55 AMG S65 AMG front right
8		FAT-MB-007	220 320 6113 220 320 0913 220 320 91 13 220 320 89 13 220 320 60 13	W220 (03-06) with ABC S55 AMG S65 AMG rear left
9		FAT-MB-008	220 320 6213 220 320 1813 220 320 90 13 220 320 92 13	W220 (03-06) with ABC S55 AMG S65 AMG rear right
10		FAT-MB-113	221 320 61 13 221 320 77 13 221 320 01 13	W221 S-Class ABC Shock Absorber front left
11		FAT-MB-114	221 320 62 13 221 320 78 13 221 320 02 13	W221 S-Class ABC Shock Absorber front right

12		FAT-MB-115	221 320 87 13 221 320 63 13 221 320 89 13 221 320 03 13	W221 S-Class ABC Shock Absorber rear left
13		FAT-MB-116	221 320 88 13 221 320 64 13 221 320 90 13 221 320 04 13	W221 S-Class ABC Shock Absorber rear right
14		FAT-MB-017	230 320 45 13 230 320 29 13 230 320 87 13	R230 ABC hydraulic Shock Absorber front left
15		FAT-MB-018	230 320 28 13 230 320 44 13 230 320 88 13	R230 ABC hydraulic Shock Absorber front right
16		FAT-MB-019	230 320 05 13 230 320 42 38	R230 ABC hydraulic Shock Absorber rear right
17		FAT-MB-020	230 320 02 13 230 320 41 38	R230 ABC hydraulic Shock Absorber rear left
W220				
18		FAT-MB-001	2203202438 A 220 320 24 38 2203205113 A 220 320 51 13	Mercedes S-Class W220 2003-2006 Front
19		FAT-CMB-001K	2203202438 A 220 320 24 38 2203205113 A 220 320 51 13(CORE)	Mercedes S-Class W220 2003-2006 Front
20		FAT-MB-138	2203202138 A 220 320 21 38	Mercedes S-Class W220 4matic Original 2003-2006 front left
21		FAT-MB-238	2203202238 A 220 320 22 38	Mercedes S-Class W220 4matic Original 2003-2006 front right
22		FAT-MB-003	2203202338 A 220 320 23 38 2203205013 A 220 320 50 13	Mercedes S-Class W220 2WD/4matic 2003-2006 Rear
23		FAT-CMB-003K	2203202338 A 220 320 23 38 2203205013 A 220 320 50 13	Mercedes S-Class W220 2WD/4matic 2003-2006 Rear CORE
W221				
24		FAT-MB-011	2213204913 A 221 320 49 13 2213209313 A 221 320 93 13	Mercedes-Benz W221 S350 S500 Front

25		FAT-CMB-011K	2213204913 A 221 320 49 13 2213209313 A 221 320 93 13 core	Mercedes-Benz W221 S350 S500 Front core
26		FAT-MB-438	2213200438 A 221 320 04 38 2213205313 A 221 320 53 13 2213201738 A 221 320 17 38	Mercedes CL-Class W216 S-Class W221 4matic front left
27		FAT-MB-538	2213200538 A 221 320 05 38 2213205413 A 221 320 54 13 2213201838 A 221 320 18 38	Mercedes CL-Class W216 S-Class W221 4matic front right
28		FAT-CMB-438K	2213200438 A 221 320 04 38 2213205313 A 221 320 53 13 2213201738 A 221 320 17 38	Mercedes CL-Class W216 S-Class W221 4matic front CORE
29		FAT-MB-013	2213205513 A 221 320 55 13 2213202113 A 221 320 21 13 2213201338 A 221 320 13 38 2213205713 A 221 320 57 13	Mercedes S-Class W221 S350 S500 2WD/4matic CL-Class W216 rear left
30		FAT-MB-014	2213205613 A 221 320 56 13 2213202213 A 221 320 22 13 2213201438 A 221 320 14 38 2213205813 A 221 320 58 13	Mercedes S-Class W221 S350 S500 2WD/4matic CL-Class W216 rear right
31		FAT-MB-223	2223200113	W222 FRONT LEFT 14-16 MERCEDES-BENZ FRONT LEFT AIR SUSPENSION STRUT SHOCK OEM W222 S550
32		FAT-MB-224	2223200213 2223204813	W222 FRONT RIGHT 14-16 MERCEDES-BENZ FRONT RIGHT AIR SUSPENSION STRUT SHOCK OEM W222 S550
33		FAT-MB-225	2223200115 A2223207313 A2223200313	14-16 MERCEDES-BENZ REAR LEFT AIR SUSPENSION STRUT SHOCK OEM W222 S550
34		FAT-MB-226	2223200213	14-16 MERCEDES-BENZ REAR RIGHT AIR SUSPENSION STRUT SHOCK OEM W222 S550
W164				
35		FAT-MB-103	1643206013 A 164 320 60 13 1643205813 A 164 320 58 13 1643204513 A 164 320 45 13 1643202213 A 164 320 22 13 1643204313 A 164 320 43 13 1643204613 A 164 320 46 13	Mercedes-Benz W164/ML350 ML500 2005-2011 front
36		FAT-MB-104	1643206113 A 164 320 61 13 1643204413 A 164 320 44 13 1643204513 A 164 320 45 13 1643205913 A 164 320 59 13	Mercedes-Benz W164 GL450 without ADS 2006-2010 front
37		FAT-MB-130	1643200130 A 164 320 01 30 1643200131 A 164 320 01 31	Mercedes-Benz W164/ML350 front CORE without ads



38		FAT-CMB-103K	1643206013 A 164 320 60 13 CORE	Mercedes-Benz W164/ML350 ML500 front CORE
39		FAT-MB-106	1643205813 A 164 320 58 13	Mercedes-Benz W164/GL rear without ADS
40		FAT-MB-105	164 320 20 31 164 320 22 31 164 320 07 31 164 320 27 31 164 320 30 31	Mercedes-Benz W164/ML rear with ADS
W251				
41		FAT-MB-100	2513203113 A 251 320 31 13 2513203013 A 251 320 30 13 2513205613 A 251 320 56 13 2513205713 A 251 320 57 13 Bilstein: 44-121167,44-111533	Mercedes R-Class W251 2006-2010 front
42		FAT-MB-251	2513203713 A 251 320 37 13 2513200730 A 251 320 07 30 2513200330 A 251 320 03 30 2513202213 A 251 320 22 13	Mercedes-Benz W251 without ADS front
43		FAT-MB-101	2513203131 A 251 320 31 31 2513203031 A 251 320 30 31 2513202931 A 251 320 29 31 2513201031 A 251 320 10 31 2513201931 A 251 320 19 31 2513201831 A 251 320 18 31	Mercedes-Benz W251/R300 with ADS rear
44		FAT-MB-102	2513202231 A 251 320 22 31 2513200731 A 251 320 07 31 2513201331 A 251 320 13 31 2513202131 A 251 320 21 31	Mercedes-Benz W251/R300 without ADS rear
W211				
45		FAT-MB-037	2113205513 A 211 320 55 13 2113206113 A 211 320 61 13 2113209313 A 211 320 93 13 2113205338 A 211 320 53 38 2113206313 A 211 320 63 13 2193200313 A 219 320 03 13	Mercedes W211 E-Class 2WD 2002-2009 front left
46		FAT-MB-038	2113205413 A 211 320 54 13 2113206013 A 211 320 60 13 2113209413 A 211 320 94 13 2113205438 A 211 320 54 38 2113206413 A 211 320 64 13 2193200413 A 219 320 04 13	Mercedes W211 E-Class 2WD 2002-2009 front right
47		FAT-MB-2800	2113262800	W211 rear
48		FAT-MB-438	2113209613 A 211 320 96 13 2113202038 A 211 320 20 38	Mercedes E-Class W211 S211 W207 4matic 2002-2009 front right
49		FAT-MB-437	2113209513 A 211 320 95 13 2113201938 A 211 320 19 38	Mercedes E-Class W211 S211 W207 4matic 2002-2009 front left
W240				

50		FAT-MB-913	A 240 320 19 13 2403201913 15.1400-0459.4 071206030706	Maybathe W240 front left
51		FAT-MB-013	A 240 320 20 13 2403202013 15.1400-0460.4 080731175937	Maybathe W240 front right
W166				
52		FAT-MB-313	1663201313 A 166 320 13 13 1663206913 A 166 320 69 13 1663207113 A 166 320 71 13 1663201313 A 166 320 13 13 1663202738 A 166 320 27 38 1663204713 A 166 320 47 13	Mercedes GL-Class, ML-Class (X166/W166 w/Airmatic) front left
53		FAT-MB-413	1663201413 A 166 320 14 13 1663206813 A 166 320 68 13 1663207013 A 166 320 70 13 1663207213 A 166 320 72 13 1663201413 A 166 320 14 13 1663202838 A 166 320 28 38	Mercedes GL-Class, ML-Class (X166/W166 w/Airmatic) front right
54		FAT-MB-502	1663202613 A 166 320 26 13 1663207413 A 166 320 74 13 1663205066 A 166 320 50 66	Mercedes GL-Class, ML-Class (X166/W166) without ADS front right
55		FAT-MB-503	1663202513 A 166 320 25 13 1663207313 A 166 320 73 13 1663204966 A 166 320 49 66	Mercedes GL-Class, ML-Class (X166/W166) without ADS front left
56		FAT-MB-167	166 320 00 30 166 320 11 30	Mercedes-Benz W166 ML-Class, X166 GL-Class Without ADS 2011-
57		FAT-MB-166	1663200130 A 166 320 01 30	Mercedes-Benz W166 rear with ads 2011-
58		FAT-MB-500	1663202613 A 166 320 26 13 1663207413 A 166 320 74 13 1663205066 A 166 320 50 66	Mercedes GL-Class, ML-Class (X166/W166) without ADS front core
W212				
59		FAT-MB-212R	2123203238 A 212 320 32 38 2123200813 A 212 320 08 13 2123202338 A 212 320 23 38 2123201838 A 212 320 18 38	Mercedes Benz W212 S212 E-Class CLS- Class C218 CLS63 E63 Front Right
60		FAT-MB-212L	2123203138 A 212 320 31 38 2123200913 A 212 320 09 13 2123202238 A 212 320 22 38 2123201738 A 212 320 17 38	Mercedes Benz W212 S212 E-Class Front Left
C218				
61		FAT-MB-218R	2183206613 A 218 320 66 13 2183203213 A 218 320 32 13	Mercedes Benz CLS-Class C218 CLS63 E63 Front Right

62		FAT-MB-218L	2183206513 A 218 320 64 13 2183203113 A 218 320 31 13	Mercedes Benz CLS-Class C218 CLS63 E63 Front Left
				
S/N	PICTURE	FAT NO.	OEM NO.	MODEL
A8 D3 4E				
63		FAT-Audi-007	4E0616039AF 4E0616039AH 4E0616039T 4E0616039 4E0616039AB 4E0 616 039 AF	Audi A8 (D3,4E) 2002-2011 front left
64		FAT-Audi-006	4E0616040AF 4E0616040 4E0616040T 4E0616040AH 4E0616040AB 4E0 616 040 AF	Audi A8 (D3,4E) 2002-2011 front right
65		FAT-AUDI-031T	4G0616031AD 4G0616039T 4G0616031T 4G0616031AA 4G0616031J 4G0616031L	Audi A6 (4G, C7, Avant) 2011, A6 (4G, C7) Allroad 2011, A7 Sportback 2010 Rear
66		FAT-AUDI-008	4E0616002G 4E0616002E 4E0616002N	Audi A8 (D3,4E) 2002-2011 rear right
67		FAT-AUDI-009	4E0616001G 4E0616001E 4E0616001N	Audi A8 (D3,4E) 2002-2011 rear left
A8 (D4, 4H)A6 (4G, C7, Avant),A6 (4G, C7) Allroad, A7 Sportback 2010				
68		FAT-AUDI-010	4G0616039L 4G0616039N 4G0616039AD 4H0616039H 4H0616039G 4H0616039F	A8 (D4, 4H) 2010,Audi A6 (4G, C7, Avant) 2011, A6 (4G, C7) Allroad 2011, A7 Sportback 2010, front
69		FAT-AUDI-012	4H6616002F 4H6616002G 4H0616002M 4H0616002C 4H0616002N	Audi A8 (D4, 4H) 2010 rear right
70		FAT-AUDI-011	4H6616001F 4H6616001G 4H0616001M 4H0616001C 4H0616001N	Audi A8 (D4, 4H) 2010 rear left
A6 (C6, 4F)				
71		FAT-Audi-013	L:4F0.616.039.Q F308611301 4F0616039N 4F0616039P 4F0616039Q 4F0616039S 4F0616039R	Audi A6 (C6, 4F) Allroad 2007-2010 front left
72		FAT-Audi-014	R:4F0.616.040.Q F308611302 4F0616040N 4F0616040P 4F0616040Q 4F0616040S 4F0616040R	Audi A6 (C6, 4F) Allroad 2007-2010 front right
73		FAT-AUDI-6031	4F0616031M	Audi A6 (C6, 4F) Allroad rear left With Sensor ADS Damper











74		FAT-Audi-6032	4F0616032M	Audi A6 (C6, 4F) Allroad REAR RIGHT With Sensor ADS Damper
A6 (4B,C5)				
75		FAT-AUDI-001	4Z7616051D 4Z7616051B 4Z7413031A 4Z7698507	Audi A6 (4B, C5) Allroad, Quattro 2000-2006 front
76		FAT-AUDI-002R	4Z7616020A 4Z7513032A 4Z7616052A	Audi (4B,C5) Allroad Quattro 1999-2006 rear right
77		FAT-AUDI-002L	4Z7616019A 4Z7513031A 4Z7616051A	Audi (4B,C5) Allroad Quattro 1999-2006 rear left
78		FAT-CAUDI-001K	4Z7616051D 4Z7616051B 4Z7413031A 4Z7698507 CORE	Audi A6 (4B, C5) Allroad, Quattro 2000-2006 front CORE
79		FAT-CAUDI-002K	4Z7616020A 4Z7513032A 4Z7616052A CORE	Audi (4B,C5) Allroad Quattro 1999-2006 rear right CORE
80		FAT-CAUDI-003K	4Z7616019A 4Z7513031A 4Z7616051A CORE	Audi (4B,C5) Allroad Quattro 1999-2006 rear left CORE
Q7/Porsche Cayenne/VW Touareg				
81		FAT-AUDI-039	7L6 616 039D 7L8616039D 7L6616039D 7L5616039E 7L6616039E 7L6616039	Audi Q7/Porsche Cayenne/VW Touareg 2002-2010 front left
82		FAT-AUDI-040	7L6 616 040D 7L8616040D 7L6616040D 7L5616040E 7L6616040 7L5616040E	Audi Q7/Porsche Cayenne/VW Touareg 2002-2010 front right
83		FAT-AUDI-039S	7L6 616 039D core 7L8616039D core 7L6616039D 7L5616039E 7L6616039E 7L6616039	Audi Q7/Porsche Cayenne/VW Touareg 2002-2010 air suspension core strut
84		FAT-AUDI-040S	7L6 616 040D core 7L8616040D 7L6616040D 7L5616040E 7L6616040 7L5616040E	Audi Q7/Porsche Cayenne/VW Touareg 2002-2010 front right core strut
85		FAT-AUDI-041	(L)7L5 6512 021E 7L8616019C 4L0616019 15.1400-0585.4 4L0616019 4L0616019B 7L8616001	Audi Q7 VW Porsche 2004-2010 rear left
86		FAT-AUDI-042	(R)7L6 6512 022E 7L8616020C 4L0616019 15.1400-0420.4 7L8616020A 4L0616020	Audi Q7 VW Porsche 2004-2010 rear right

87		FAT-AUDI-043	7P6 616 039N 7P6 616 039K 7P6 616 039R 7P6616039H 7P6616039M		Audi Q7 VW Porsche New model front left
88		FAT-AUDI-044	7P6 616 040N 7P6 616 040K 7P6 616 040R 7P6616040H 7P6616040L		Audi Q7 VW Porsche New model front right
89		FAT-AUDI-045	7L5616019F 616 019K	7L6	Audi Q7 VW Porsche rear left New model
90		FAT-AUDI-046	7L5616020F 616 020K	7L6	Audi Q7 VW Porsche rear right New model
VW Phaeton/Bentley					
91		FAT-VW-008	3W5616040B 3D0616040T 3D0616040 3D5616040 3D7616040 3D0616040L		VW Phaeton/Bentley Continental GT front right
92		FAT-VW-009	3W5616039B 3D0616039 3D5616039 3D7616039 3D0616039L 3D0616039M		VW Phaeton/Bentley Continental GT front left
93		FAT-VW-016	3D0616002 3D0616002H 3D0616002N		VW Phaeton REAR RIGHT
94		FAT-VW-017	3D0616001 3D0616001F 3D0616001G 3D0616001N		VW Phaeton REAR LEFT
95		FAT-BY-001D	3W5616001D		BENTLEY Continental Flying Spur REAR LEFT 2005-2011
96		FAT-BY-002D	3W5616002D		BENTLEY Continental Flying Spur REAR RIGHT 2005-2011
Porsche Panamera					
97		FAT-PR-001	97034305108 97034305109 97034305110 97034305111 97034305112 97034305114		Porsche Panamera front left
98		FAT-PR-002	97034305208 97034305209 97034305210 97034305211 97034305212 97034305214		Porsche Panamera front right

99		FAT-PR-003	97033316104	Porsche Panamera REAR LEFT
100		FAT-PR-004	97033306106	Porsche Panamera REAR RIGHT



Land Rover/LEXUS/HYUNDAI/JAGUAR

S/N	PICTURE	FAT NO.	OEM NO.	MODEL
Land Rover				
101		FAT-LD-444	LR024444 LR051483 LR056268 LR057931	RangeRover Evoque 12-16 with Magnetic Damping Front right
102		FAT-LD-445	LR024437 LR051481 LR056266 LR057930 LR070932	RangeRover Evoque 12-16 with Magnetic Damping Front left
103		FAT-LD-446	LR024447 LR044687 LR051497 LR056269 LR063741 LR079421	RangeRover Evoque 12-16 with Magnetic Damping Rear right
104		FAT-LD-447	LR024440 LR044682 LR051491 LR056267 LR063740 LR079420	RangeRover Evoque 12-16 with Magnetic Damping Rear left
105		FAT-LD-620	RNB501250 RNB501580 RNB501620 RNB501460 RNB501600 RNB501470	Discovery 3/4 2004-2012 Range Rover Sport 2006-2013 without ADS front
106		FAT-LD-006	RTD501090 RPD500880 RPD000306 RPD000308 RPD000309	Discovery 3 WITHOUT ADS rear
107		FAT-LD-621	RNB501620	Range Rover Sport 2005-2009 front with ads
108		FAT-LD-622	LR023234 LR015018 LR015018;LR015020;LR020000;LR02001;LR 032651;LR032652	LAND ROVER REAR AIR SPRING RANGE ROVER SPORT 10-13
109		FAT-CLD-006K	RTD501090 RPD500880 RPD000306 RPD000308 RPD000309	Discovery 3 rear CORE strut
110		FAT-CLD-632K	RTD501090	Bilstein B4 Rear Air Shock LR Discovery Mk4 (La) 3.0 core

111		FAT-LD-002	RNB000750G RNB000750 RNB501530 RNB000750 Lnsk1126 DG10006A	Range Rover 2003-2009 (L322) front left
112		FAT-LD-003	(R)RNB000740G RNB501520 RNB000740 Lnsk1127 DG10007A RNB501520	Range Rover 2003-2009 (L322) front right
113		FAT-LD-005C	RNB000750	Range Rover 2003-2009 (L322) front LEFT CORE
114		FAT-LD-006C	RNB000740	Range Rover 2003-2009 (L322) front LEFT RIGHT CORE
115		FAT-LD-3352	3352 6753057 11986710 RPD500940	Land Rover Air Suspension Shock Absorber For 03 06 Range Rover Hse 4.4i V8 Rear Passenger Shock Strut
116		FAT-LD-004	L2023560 L2012859 LR032560	Range Rover with ADS Brand new Original front right
117		FAT-LD-005	L2023567 L2012885 LR032567	Range Rover with ADS Brand new Original front left
118		FAT-LD-2995	LR012995 LR012997 LR023580 LR012996 LR020529 LR023573	L322 Range Rover Air Suspension , Vogue 2010 - 2012 MK III Land Rover Rear Shock Absorber
119		FAT-LD-0155	LR060399 LR060401 LR060155 LR060402	Land Rover Range Rover Sport with EDC solenoid Rover Executive FRONT
120		FAT-LD-1155		Land Rover Range Rover Sport with EDC solenoid Rover Executive REAR
121		FAT-LD-1123	22271123	RANGE ROVER VOGUE 2014 L405 RIGHT FRONT SHOCK WITHOUT EDC
122		FAT-LD-1694	6H42-5B694-AB	Land Rover Air Suspension Shock Absorber For 03 06 Range Rover Hse 4.4i V8 Rear Passenger Shock Strut WITHOUT EDC
				
123		FAT-JA-001	C2C41347 F308609003/-/07 0490113123303428 C2C41349 C2C41339 C2C41347	XJR XJ6 XJ8 Jaguar front

124		FAT-JA-002	C2C41340 F308609001/F/02 043033065108111 C2C41341 C2C41343 C2C41340	XJR XJ6 XJ8 Jaguar rear
125		FAT-LS-001	L48010-50240 4801050240	Lexus LS460 front left
126		FAT-LS-002	R48020-50242 4802050242	Lexus LS460 front right
127		FAT-LS-003	48080-50211	Lexus LS460 rear left
128		FAT-LS-004	4809050232	Lexus LS460 rear right
129		FAT-LS-431R	48010-50120	LEXUS LS430 LS400 FRONT Right 2000-2006
130		FAT-LS-431L	48010-50130	LEXUS LS430 LS400 FRONT LEFT 2000-2006
131		FAT-LS-430R	48080-50130	LEXUS LS430 LS400 Rear Right 2000-2006
132		FAT-LS-430L	48090-50120	LEXUS LS430 LS400 Rear Left 2000-2006
133		FAT-LS-004L	48010-50340	Lexus LS 600h LS600hL Air Shock Strut FRONT LEFT
134		FAT-LS-004R	48020-50340	Lexus LS 600h LS600hL Air Shock Strut FRONT RIGHT
135		FAT-LS-005L	48090-50201	LEXUS-LS-600h-AWD-2009-LHD-AIR- SHOCK-ABSORBER-REAR-LEFT- NEAR-SIDE
136		FAT-LS-005R	48080-50202	LEXUS LS 600h AWD 2009 LHD AIR SHOCK ABSORBER REAR RIGHT OFF SIDE

137		FAT-HY-002	54606-3N505 54606-3N506 54621-3M500 54606-3N507 54621-3N800 54606-3N510 54606-3N517	Hyundai Genesis 2008, Hyundai Equus/Centennial 2009-2013 front right
138		FAT-HY-001	54605-3N505 54605-3N506 54611-3M500 54605-3N507 54611-3N800 54606-3N516 54605-3M500	Hyundai Genesis 2008, Hyundai Equus/Centennial 2009-2013 front left
 BMW				
S/N	PICTURE	FAT NO.	OEM NO.	MODEL
E65 E66 G11/G12				
139		FAT-BMW-7560	37106877560 37106874598	BMW 7er (G11/G12) 2015 Front right
140		FAT-BMW-7559	37106877559 37106874597	BMW 7er (G11/G12) 2015 Front left
141		FAT-BMW-4594	37106874594	BMW 7er (G11/G12) 2015 Rear right
142		FAT-BMW-4593	37106874593	BMW 7er (G11/G12) 2015 Rear left
143		FAT-BMW-725	3712 6797 025	BMW F25/X3 front with sensor LEFT
144		FAT-BMW-726	3712 6797 026	BMW F25/X3 front with sensor RIGHT
145		FAT-BMW-538	3712 6785 538 3710 6767 864 3710 6778 800 3712 6758 574	BMW E65/E66 740 745 750 760 (without solenoid) 2001-2008 rear right
146		FAT-BMW-537	3712 6785 537 3710 6767 863 3710 6778 799 3712 6758 573	BMW E65/E66 740 745 750 760 (without solenoid) 2001-2008 rear left
147		FAT-BMW-002	3712 6785 535 3710 6778 797 3712 6758 579 3712 6758 581 3712 6767 127	BMW E65/E66 with EDC 2001-2008 rear left
148		FAT-BMW-003	3712 6785 536 3710 6778 798 3712 6758 580 3712 6758 582 3712 6767 128	BMW E65/E66 with EDC 2001-2008 rear right
F01 F02 F04				

149		FAT-BMW-004	LL679413902 09B3342C2345 15.1400-0835.4 37126791675 37126794139 37126796929	BMW F02 rear left
150		FAT-BMW-005	LR406427601 08B2792C3244 15.1400-0700.4 37126791676 37126794140 37126796930	BMW F02 rear right
151		FAT-BMW-009	7116863147, 37116851125 6863147	BMW F02 FRONT LEFT SHOCKBMW 7er F01, F02, F03, F04 FL LCI Federbein Stossdämpfer vorne links VDC
152		FAT-BMW-010	37116863148 6863148	BMW F02 FRONT Right SHOCK BMW 7er F01 F02 FL LCI Federbein Stossdä mpfer vorne rechts VDC 6863148
153		FAT-BMW-011	37116796939 37116851127	BMW 7er F01 F02 37116851128, 7er F02 FL LCI 740LiX 750LdX 750LiX, 7er F01 FL LCI 730dX 740dX 750dX 750iX FL LCI Federbein VDC 6851127
154		FAT-BMW-012	37116796940 37116851128	BMW 7er F01 F02 FL LCI 37116851128, 7er F02 FL LCI 740LiX 750LdX 750LiX, 7er F01 FL LCI 730dX 740dX 750dX 750iX Federbein VDC 6851128
155		FAT-BMW-006	37126858812 37106791676 37126794140 37124065094 37124064276 37126796938	BMW 7er (F01/F02/F04) 2007 rear right
156		FAT-BMW-007	37126858811 37106791675 37126794139 37124065093 37124064275 37126796937	BMW 7er (F01/F02/F04) 2007 rear left
E53				
157		FAT-BMW-501	37116757501 37116761443	BMW X5 E53 99-06 front left
158		FAT-BMW-502	37116757502 37116761444	BMW X5 E53 99-06 front right
159		FAT-BMW-503	37116757501 37116761443 CORE	BMW X5 E53 99-06 Repair kits front left
160		FAT-BMW-504	37116757502 37116761444 CORE	BMW X5 E53 99-06 Repair kits front right
 American car				
S/N	PICTURE	FAT NO.	OEM NO.	MODEL

161		FAT-FORD-099	3L1Z18A099AA 3L1Z18124DA 6L1Z3C199AA	03-06 Ford Expedition All Models 03-06 Lincoln Navigator All Models front
162		FAT-FORD-100	6L1Z18A099DA 3L1Z18125AB 4L1Z5A891AA	03-06 Ford Expedition All Models 03-06 Lincoln Navigator All Models rear
163		FAT-FORD-101	6L74-5A965-AC	Lincoln Navigator 2003-2006 rear
164		FAT-FORD-102	25979391 1575626 25979393 22187156 25979394	GMC Yukon 1500 2000-2006 Cadillac DTS 2006-2011 rear CHEVROLET Suburban, Avalanche Tahoe
165		FAT-FORD-103	F85Z18124MC 5U2Z 18V124EA	Ford Expedition 97-02 Ford Explorer 98-00 front
TESLA				
166		FAT-TSA-001	w309250001 1027361-00-E	2015-2017 Tesla Model X rf Air Shock Absorber Strut front FRONT 2015 2016 2017
167		FAT-TSA-002	w309255002 1027461-00-E	2015 2016 2017 TESLA MODEL X REAR AIR SHOCK ABSORBER STRUT OEM
168		FAT-TSA-003	600351-00-C	TESLA MODEL S AIR SHOCK ABSORBER STRUT FRONT 2012 2013 2014 2015 600351-00-C front
169		FAT-TSA-004	6006352-00-C	TESLA TESLA MODEL S AIR SHOCK ABSORBER STRUT FRONT 2012 2013 2014 2015 rear
Jeep				
170		FAT-JP-902R	68029902AE 68029902AB 68029902AC 68029902AD 68080194AB 68080194AA 68059904AD 68059904AB 68059904AC	jeep grand cherokee wk2 Chrysler front right
171		FAT-JP-902L	68029903AE 68029903AC 68029903AD 68080195AB 68080195AA 68059905AD 68059905AB 68059905AC	jeep grand cherokee wk2 Chrysler front left

345.99

